Total Encasement Mattress Cover for Sleep Number 360™ Smart Beds

Thanks for purchasing the Total Encasement Mattress Cover for Sleep Number 360™ Smart Beds. We wish you many nights of restful sleep!

Follow these simple instructions to install your new mattress cover:





Remove your Total Encasement Mattress Cover from its packaging and unzip fully. Beginning at the foot of the bed, align the Logic™ Label on the mattress cover with the label on your Sleep Number® bed.



Lift the mattress slightly as you slide the bottom of the mattress cover under the mattress. (This is most easily done with two people.) Slide the cover up half way.

Avoid pulling excessively on the seams.

*If you have a FlexFit™ adjustable base, carefully disengage the magnets that connect the mattress to the base so the mattress cover can slip between. (There are two sets of magnets on each side of the bed.)



Disconnect the hose on one side of the mattress from the bed's air chamber by pushing on the tab at the end of the hose and pulling gently.



Line up the hose covering on the mattress cover with the hose connector on the mattress. Pass the hose through the hose covering and reconnect to the air chamber by pressing until you hear a click.



Tighten the hose covering by wrapping the attached Velcro strap tightly around it. (This is important to ensure allergen protection.)

Repeat steps 3-5 on the other side of the mattress.





Pull the mattress cover the rest of the way up to completely cover the mattress, and zip closed. The hose coverings will fit into the depressions on each side of your FlexFit™ adjustable base or integrated base where the hoses emerge from the base.

If you do not have one of these bases, the hose coverings will rest between the mattress and the platform beneath.



Now you're ready to enjoy your mattress cover. Sleep well!

